

IMPRESSION INSTRUCTIONS

To get the best performance and sound from your new custom monitors, it is essential that we get a high quality impression of your ears.

This requires a **high quality silicone impression** of your ears taken **past the second bend with a 1" bite block**. Please do not hold your mouth open without a 1" block, chew or talk while your impression is being taken. **Please read the information below to ensure you get a great impression of your ears.**

NEXT STEPS

- 1. Schedule an appointment with an audiologist** to have your impressions taken of your ears.
- 2. Have your impressions taken.** The audiologist will examine your ears to ensure they are healthy and clean before taking the impressions. **Please share the instructions below with your audiologist.**
The audiologist will give the completed impressions to you. The cost of the impressions is paid by you directly to the audiologist.
- 3. Send us your impressions.** Please include the form below.

AUDIOLOGIST INSTRUCTIONS

Use a high quality two-part silicone impression material. Please give impressions to the customer they will send to us. For questions call us at 02 4954 4771.

Please ensure the impressions are:

- Full anatomy of the ear
- Past the second bend of the ear canal
- Made with an open jaw using a 1" bite block
- Free of voids



Do not take an impression without a bite block or while chewing. Using a bite block is essential for obtaining a great seal & fit on the final product.

**Complete . Detach . Send
with impressions to:**

EARZONE
2/246 Macquarie Road
Warners Bay NSW 2282

Still have questions?

E: info@earzone.com.au
P: 02 49544771

Name (of IEM user)

Order No

Notes